

Cisco Analogue Telephone Adaptor (ATA) – Set-up Guide




Contained in the box


(please note, cables may vary in colour)



Power
Cable




NZ Power
Adaptor



Telephone
Cable (RJ11)




Network
Cable (RJ45)



Analogue
Telephone
Adaptor

1 Connect Analogue Telephone Adaptor (ATA) to power supply

Take the ATA **E** out of the box. Attach power cable **A** to the NZ power adaptor **B** then plug power cable into the back of the ATA and into a power outlet. The ATA will turn on within a couple of minutes. When the  LED is a steady green, the system has booted up successfully.




2 Connect Analogue Telephone Adaptor (ATA) to phone

Take the telephone cable from your existing phone or use the supplied telephone cable **C** and plug it into the back of the ATA **E** into PHONE 1. If your device is configured for 2 lines, plug the second line into PHONE 2.










3 Connect Analogue Telephone Adaptor (ATA) to the internet

Take network cable **D** and plug it into the network port at the back of the ATA **E** then plug the other end of the cable into a spare LAN port on your modem or network switch. The  LED should start to flash green.



4 Your phone line is now ready to use

Your phone will be ready to use when the lights on the ATA **E** are on. You should see a green   and  LED for a 1 PHONE configuration and a green    and  LED for a 2 PHONE configuration. Please allow up to 2 minutes for this.



For more info, guides & FAQs visit <https://one.nz/one-business-with-webex/help> or scan the QR code

